

## TRUCK TORQUE-ROD BUSH REMOVAL/ INSTALLATION PAT. M307531



\* Put Torque-Rod into the main body with necessary accessories. \* Stepping on the foot plate of air pump until the bush comes out.

Rating: Not Rated Yet

Price:

Sales price:

Discount:

[Ask a question about this product](#)

Manufacturer: [HCB Specialty Tools](#)

Description 

### Product Description :

**TRUCK TORQUE-ROD BUSH REMOVAL/ INSTALLATION PAT. M307531**

?Product Info?

Model/Item No. :

**H.C.B-A1170**

Country of Origin :

**Taiwan**

Brand :

**H.C.B**

Product Specifications /Features :

\* Put Torque-Rod into the main body with necessary accessories.

\* Stepping on the foot plate of air pump until the bush comes out.

Primary Competitive Advantages :

**Well and High Quality Control, Prompt Delivery, Competitive Prices**

Patent No./Country :

**PAT. M307531**

Sales Method :

**Export, Manufacture**

Payment Term :

**T/T, L/C at Sight**

**on car :**



1 / 54.5 / 71 / 5.8"

www.hcb-autotools.com

NO.	Description
A1170-1	MAIN BODY L358XW160X(H151)(mm)
A1170-2	30 TON HYDRAULIC CYLINDER (STROKE 130mm)
A1170-3	φ103X98L RING PIVOT
A1170-4	φ138X35L NUT (FIXED ONTO HYDRAULIC) (M88X2.0)
A1170-5	INSERTION SUPPORT SLEEVE (φ138X30L)
A1170-6	C-SHAPE FIXED BASE
A1170-7	TORQUE-ROD LOCK BAR (M14XP2.0)
A1170-8	TRAILER (L375XW180XH110mm)
A1170-9	AIR PUMP (OIL RESERVOIR CAPACITY 1,800 C.C.)



REMOVAL :



1) Firstly, the inspection of fitting bush into the part.  
2) Keep stepping on the foot plate of air lock until the independent bush comes out. (Without obstructing the working process of air pump)

INSTALLATION :



1) Keep stepping on the foot plate of air lock until the independent body is combined with Torque-Rod. (Without obstructing the working process of air pump)